



#### **INSTRUCTIONS FOR CLEANING EYEGLASSES WITH ANTI REFLECTIVE COATING**

**Lenses with AR Coating : For best results for cleaning the lenses please do the following:**

- 1. Wash the lenses with cold/lukewarm water to remove the dust particles (with the dust removed there is nothing to scratch the lenses).**
- 2. Drop a small drop of dish washing liquid on your wet fingers and gently rub the wet lenses.**
- 3. Rinse with cold/lukewarm water.**
- 4. Dry with a clean 100% cotton or microfiber cloth. Lenses with hydrophobic coating have just 1 or 2 drops of water to blot.**
- 5. Do not use any other eye cleaners or other cleaning products with any chemicals, they will destroy the AR coating that is on the glasses.**

**Thank you for your order! We take pride in offering a wide variety of leading-edge eye wear at reasonable prices, including 20% off any purchase of our night-driving and computer glasses!**

**We hope that you enjoy your new computer glasses!**

**We have included a FREE microfiber pouch to assist in protecting your glasses.**

**We want to know what you think of our glasses. Please send us your product comments/testimonials using our Contact Us page at: <http://www.vseyewear.com/store-comp/>**

**We also are offering the following special offer: 20% off on all of our Sheer Vision and Sheer Glare Computer Eyewear!**